

Profilam Junior A3

PL Instrukcja obsługi

1 Zasady bezpieczeństwa:

- Przed rozpoczęciem pracy z urządzeniem, należy zapoznać się z zasadami bezpieczeństwa, zaleceniami producenta i instrukcją obsługi. Instrukcję należy zachować i korzystać z niej w przypadku jakichkolwiek wątpliwości dotyczących obsługi urządzenia.
- Urządzenie należy ustawić na stabilnym podłożu w pobliżu gniazdka o napięciu 220 -240 V 50/60 Hz.
- Urządzenie należy chronić przed wilgocią i kurzem.
- Nie wolno ustawiać urządzenia w pobliżu urządzeń grzejnych lub wentylacyjnych.
- Nie wolno używać urządzenia w pobliżu łatwopalnych gazów lub cieczy.
- Na urządzeniu nie wolno kłaść przedmiotów ciężkich lub posiadających ostre krawędzie.
- Należy chronić przewód zasilający urządzenia przed uszkodzeniem. Nie używać przewodu do przenoszenia urządzenia i wyciągania wtyczki z gniazdka. W razie uszkodzenia należy wymienić przewód zasilający.
- Urządzenie należy całkowicie wyłączyć z sieci po zakończeniu pracy lub gdy jest przenoszone.
- Całkowite wyłączenie urządzenia następuje po wyjęciu wtyczki z gniazda zasilającego.
- Urządzenie należy trzymać poza zasięgiem dzieci.
- Urządzenie zawiera elementy obrotowe, które mogą spowodować wciągnięcie luźnych elementów garderoby, włosów itp. Należy zachować ostrożność!
- UWAGA! Urządzenie posiada elementy grzejne! Nie wolno dotykać powierzchni urządzenia lub kłaść na niej łatwopalnych materiałów!
- Po zakończeniu pracy należy wyłączyć urządzenie, a następnie wyciągnąć wtyczkę z gniazdka zasilającego. Nie wolno zastraniać szczelin, aby wałki grzejne mogły ostygnąć.
- Nie wolno używać urządzenia do innych celów niż określone w instrukcji obsługi.
- Należy kontrolować sprawność urządzenia. W przypadku zauważenia jakichkolwiek nieprawidłowości w pracy, należy wyłączyć urządzenie z prądu, a następnie skontaktować się z serwisem.
- Urządzenie jest przeznaczone wyłącznie do pracy w pomieszczeniach zamkniętych, dobrze wywietrzonych, w temperaturze powyżej 8 °C
- Przed zdjęciem jakiegokolwiek osłony, należy wyjąć wtyczkę z gniazda zasilającego.
- Stosowanie niewłaściwych substancji smarujących stwarza zagrożenie pożarowe.
- Urządzenie należy obsługiwać zawsze zgodnie z ogólnymi zasadami BHP.
- W przypadku pojawienia się usterki, należy wyłączyć laminator i skontaktować się ze sprzedawcą. Wszelkich napraw urządzenia może dokonywać jedynie osoba uprawniona.

2 Zalecenia producenta:

- Używaj tylko sprawdzonych materiałów eksploatacyjnych firmy OPUS.
- Urządzenie laminuje przy użyciu folii o grubości od 80 – 250 μm . Nie należy używać folii o innej grubości.
- Przy wkładaniu dokumentu do szczeliny podawczej, nigdy NIE wkładaj go otwartym brzegiem. Grozi to wciągnięciem folii w wałki urządzenia.
- Nie używaj folii przycinanej indywidualnie, gdyż może to spowodować trudne do usunięcia zabrudzenia wałków lub nawinięcie się folii na wałki.
- Dokument przeznaczony do laminowania nie może zawierać żadnych elementów metalowych (spinacze, zszywki itp.).

UWAGA! NIESTOSOWANIE SIĘ DO POWYŻSZYCH ZALECEŃ MOŻE DOPROWADZIĆ DO UTRATY GWARANCJI.


3 PRZEWODNIK LAMINACJI

Grubość folii μm	Papier	Temp. $^{\circ}\text{C}$	
		A3	A4
80 – 100	80 g/m^2	100	100
	120 g/m^2	110	105
	200 g/m^2	115	110
125 – 150	80 g/m^2	120	115
	120 g/m^2	125	120
	200 g/m^2	130	125
175 – 200	80 g/m^2	135	130
	120 g/m^2	135	135
	200 g/m^2	140	135
250	80 g/m^2		145

Jeżeli użytkownik używa folii niskotemperaturowych należy zmniejszyć temperaturę o 15 – 20 $^{\circ}\text{C}$.

By uniknąć zniszczenia urządzenia, ustaw odpowiednią temperaturę.

4 Obsługa



1. Włącz zasilanie przełącznikiem na tylnej ścianie urządzenia.

2. W przypadku, gdy przełącznik na tylnej ścianie był włączony, naciśnij przycisk **POWER (zasilanie)**.

Wciśnij przycisk HOT (grzanie).

Początkowe ustawienia dla folii 100 μm to 100°C.

Lampka grzania miga.

3. **Gdy urządzenie będzie gotowe potwierdzi to trzema sygnałami.**

Zielona lampka będzie świecić.

Możesz rozpocząć laminowanie.

Uwaga! Włóż zamkniętą część folii do przodu.

4. **Rozpocznij laminowanie**

Gdy przywieranie laminowanego materiału nie jest zadowalające zwiększ temperaturę.


5. **Zakończenie laminacji.**

Naciśnij guzik POWER – wyłączy urządzenie.

Gdy temperatura spadnie poniżej 65°C urządzenie wyłączy się automatycznie.

Uwaga. Aby zapobiec przegrzaniu, nie wyłączaj urządzenia przed zakończeniem laminacji. Gdy właki się ochłodzą urządzenie wyda 5 sygnałów dźwiękowych i wyłączy się automatycznie.

5 Opis panelu kontrolnego



1. Ustawienie temperatury

TEMP – Modyfikacja temperatury 65 - 145°C

2. Wyświetlacz

Lampka READY – Urządzenie gotowe do laminacji

3. Funkcje przycisków

POWER – zasilanie

Wciśnięcie przycisku przez 1 sekundę włącza lub wyłącza urządzenie.

HOT – rozpoczęcie laminacji na ciepło

MEAS: pomiar aktualnej temperatury rolek

REVERSE: wycofanie laminowanego materiału

6 Rozwiązywanie problemów

Problem	Powód	Rozwiązanie
Urządzenie nie ma zasilania lub rolki się nie obracają.	Przewód sieciowy nie jest prawidłowo podłączony. Przycisk POWER wyłączony.	Sprawdź czy wtyczka jest prawidłowo podłączona.
Nadmierny hałas.	Działanie przekładni nie jest płynne.	Naciśnij przycisk POWER lub skontaktuj się ze wsparciem technicznym.
Zła laminacja.	Laminowany dokument jest pomarszczony, wilgotny lub wygięty.	Zmień temperaturę laminacji.
Brak wzrostu temperatury.	Sprawdź wtyczkę zasilania.	Sprawdź wtyczkę zasilania oraz czy przełącznik zasilania jest włączony lub skontaktuj się ze wsparciem technicznym.
Naróżniki nie są zalaminowane.	Dokument jest zbyt gruby by prawidłowo uszczelnić krawędzie folii.	Użyj cieńszego dokumentu lub pozostaw więcej miejsca na brzegach ok. 5mm.
Stan alarmowy.	Coś utknęło pomiędzy ogrzewanymi wałkami lub zmieniło pozycję.	Wyłącz urządzenie na przełączniku. Skontaktuj się ze wsparciem technicznym.

W przypadku pojawienia się innych problemów, należy skontaktować się z serwisem.

7 Dane techniczne:

• Maksymalna szerokość laminacji:	325 mm
• Maksymalna prędkość laminacji:	520 mm/min
• Maksymalna grubość folii:	250 µm
• Maksymalna grubość laminacji:	1 mm
• System grzewczy:	rolki ogrzewane od wewnątrz
• Ilość rolek grzewczych:	4
• Maks. Temperatura pracy:	145 °C
• Czas nagrzewania:	2–3 minuty
• Pobór mocy:	550 W
• Napięcie sieciowe:	220–240V, 50/60Hz, 2,6A, Bezpiecznik 250 V T6,3 A
• Wymiary (W x S x G):	115 x 480 x 211 mm
• Waga netto:	10 kg
• Waga brutto:	12 kg



Zużyty sprzęt oznakowany niniejszym symbolem nie może być umieszczany i usuwany łącznie z innymi odpadami, w tym odpadami komunalnymi. Obowiązkiem użytkownika jest przekazanie zużytego produktu do punktu zbiórki w celu recyklingu odpadów powstałych ze sprzętu elektrycznego i elektronicznego. Właściwa segregacja i selektywna zbiórka odpadów zużytego sprzętu zmniejsza negatywne oddziaływanie substancji niebezpiecznych, które mogą się w nim znajdować, na środowisko naturalne i zdrowie człowieka. W celu uzyskania bardziej szczegółowych informacji dotyczących utylizacji zużytego sprzętu prosimy skontaktować się z przedstawicielem władz lokalnych, dostawcą usług utylizacji odpadów lub punktem sprzedaży, gdzie nabyto produkt. Zapewniając prawidłową utylizację sprzętu pomagamy chronić środowisko naturalne.

Profilam Junior A3

EN User guide

1 Health & Safety precautions:

- Before operating the equipment please read the Health & Safety precautions, manufacturer's recommendations and the operation manual.
- The operation manual should be easily available at any time for the operator.
- The equipment should be installed on a sturdy level surface near a 220–240 Volt, 50 – 60 Hz AC correctly earth socket.
- The equipment:
 - Should be protected against dust and moisture.
 - Must not be placed near a heating or ventilation unit.
 - Should not be used in vicinity of inflammable liquids or gases.
 - Do not put anything on top off the equipment.
 - The power supply cable must be protected against damage.
 - Must not be used to pull or move the equipment or to remove the plug from the socket.
 - During long standstill or moving the equipment and to ensure that it is turned off completely, remove the plug from the mains socket.
 - Should be kept away and out of the reach from children and animals.
 - Must not be used for any other purposes, than those indicated in the instruction manual.
 - The equipment must not be located outside, should be operated in room temperature higher than +8°C.

Danger!

- The equipment contains electrically driven rollers. Ensure long hair, loose jewelry, ties and other loose clothing are kept away from the entry slot they could get entangled in the rollers.
- It is necessary to check and supervise, if the equipment is operated and used correctly, if there should be a malfunction, then you must contact the dealer or service team.
- The equipment must not be located outside and should be operated in a room temperature higher than +8 °C.
- Before removing any covers from the equipment, remove the power plug from a mains socket.
- Using inappropriate lubricants such as petroleum based cleaning materials, can cause a fire hazard.
- Only authorized and qualified staff may carry out any repairs during the Guarantee/Warranty period.
- The equipment must be operated in accordance with the general Health & Safety rules.
- Do not leave the equipment operating without an operator.
- Do not turn off the Laminator until it has cooled down.
- After use turn the equipment off by the switch on unit, next remove the plug from a socket if not in regular use.

2 Manufacturer's recommendations:

- Use only recommended supplies and accessories from OPUS (see www.opus.pl)
- If the equipment is switched on and is not operated for more than one hour, it could get overheated in such an instance, to avoid bad quality laminating put 1 or 2 sheet of A3 paper through in order to cool the rollers down.
- Always insert the pouch with the closed end, first into the laminator. Putting the open end first can cause bubbling and the film may rap and get stuck round the rollers inside the laminator.
- Should a document with pouch get stuck inside the laminator first use the anti-block system lever (6) the top of the unit, which separates the roller so you can pull the pouch plus document out. If unsuccessfully call your Dealer or the service team.
- When cutting tailor made shapes from the pouch it can make the rollers sticky and dirty from the glue which can cause the pouch to wind round the rollers, you must use a carrier. ASK YOUR DEALER FOR INFORMATION.
- Remove any sharp or metal elements from the document like (staples & paper clips, etc.) before laminating.

**WARNING! THE EQUIPMENT CONTAINS HEATING ELEMENTS, BE AWARE OF HIGH TEMPERATURES! !!
BURN HAZARD !!**

WARNING! NOT COMPLIANCE WITH THE RULES AND RECOMMENDATIONS ABOVE CAN VOID THE GUARANTEE/WARRANTY


3 LAMINATION GUIDE CHART

Film/pouch Microns (µm)	Paper	Temperature in °C	
		A3	A4
80 - 100	80 g/m ²	100	100
	120 g/m ²	110	105
	200 g/m ²	115	110
125 - 150	80 g/m ²	120	115
	120 g/m ²	125	120
	200 g/m ²	130	125
175 - 200	80 g /m ²	135	130
	120 g/m ²	135	135
	200 g/m ²	140	135
250	80 g /m ²		145

* If using a low temperature pouch, reduces the temperature by 15 to 20 °C (e.g. Chart 80 µm-100 °C A3. new 80 °C)

* To avoid damaging the rollers and equipment, ensure you set the correct temperature own cut shape of pouch use a carrier envelope.

4 How to Use



1. Switch on using the switch at back of equipment.
2. When you turn on the equipment by switch on the back you do not need to press the power button on the front panel.

When you switch off by the **POWER** button to standby and then restart again using the **POWER** button, you need to set the temperature required, or press the **HOT** button which is pre set to 100 °C for 100 microns (μm).

3. When ready LED goes green and you hear 3 beeps you can start laminating.

!! Warning !!

Insert the sealed end of the pouch first. Failure to do so will damage the document and rollers, which could invalidate your Warranty / Guarantee.

4. Lamination:

When the document are not sealed together satisfactory, increase the temperature and run the pouch through again.


5. Finished lamination.

Do not turn off by the main power switch, Press the **POWER** button on the panel and hold till the led screen is blank and release. When the rollers are cool and have reached below 65 °C the power stops automatically.

Warning

Do not turn off the Switch as soon as finishing lamination to prevent overheating. Follow the above method. After the roller cool down, there will be beep sound for 5 times and the power will be stopped automatically.

5 Description of Control Panel



Temperature setting (65 to 145 °C)

TEMP: Modifying temperature

LED display READY: Ready to laminate

POWER

ON – Press the power button for 1 second

OFF – Press the power button for 1 second

HOT: Start Hot lamination.

MEAS: Measure the actual temperature of rollers

REVERSE: Reverse roller direction backward

6 Trouble Shooting Guide

Malfunction	Cause	Remedy
Equipment has no power or rollers are not turning.	<ol style="list-style-type: none">1. Power cord is not properly plugged in.2. Power switch off.3. Temperature not reached.	<ol style="list-style-type: none">1. Check the power plug is properly plugged.2. Check the power switch is turned on.3. Check the temperature.4. Contact supplier or Service.
Excessive noise.	Operation of gear is not smooth.	Turn off the equipment, and then contact Supplier or Service.
Bad lamination.	Laminated document wrinkled, damp, or folded.	Adjust the temperature lower or higher.
No increase of Temp.	Check power plug.	Check if the power plug and switch is turned on or Contact supplier or Service.
Corner is not sealed.	Document is too thick to seal the edges of the film.	Use a thinner document or leave a larger margin round the edges approximately 5mm.
Emergency state.	Something may be stuck between the heated rollers or they are out of position.	Turn off the switch. Contact supplier or Service.

If you have any problem cannot be solved, please contact service the department.

7 Specifications

• Maximum:	
- laminating width	325 mm
- laminating speed	520 mm/min
- pouch thickness	250 microns (μm)
- laminating thickness	1 mm
- temperature	145 °C
• Heating System	Heated rollers
• Rollers	4
• Preheating Time	2 – 3 minutes
• Rated Consumption	550 watt
• Voltage	220–240 V, 50/60 Hz. 2.6 Amps,
• Fuse	250 V T 6.3 A
• Dimension:	H 115 x W 480 x D 211 mm
• Net weight	10 kg
• Gross weight	12 kg



Equipment and products marked with this symbol cannot be deposited together with normal or municipal waste. The user is required to take their used product to a collection point for recycling of waste electrical and electronic equipment. Proper segregation of used equipment reduces the negative impact of hazardous substances that may be in there, in to the environment which could impact, human and wild life health. For more detailed information concerning the disposal of used equipment, please contact your local authority, waste disposal service or the point of sale where you purchased the product. By ensuring proper disposal of equipment we are helping to protect the environment, humanity and wild life health.